



RF & BB Connection (Version 4003 Edit 6) for layout version 04


RF BASEBAND




RF (Version 0 Edit 19) for layout version 04




BB Block Connections (Version 4003 Edit 7) for layout version 04




UI (Version 0100 Edit 16) for layout version 04





Audio and RFI (Version 0100 Edit 12) for layout version 04






Power Supply and Charging (Version 0100 Edit 17) for layout version 04







Layout Diagram of DS7 – Top (Version 04)



Layout Diagram of DS7 – Bottom (Version 04)



Testpoints of DS7 – Top (Version 04)



Testpoints of DS7 – Bottom (Version xx)